

Applying shim tape to Ray's N8/8i Bracket

Hello, thank you for purchasing Rays bracket set, we hope you have enjoyed the extra clearance and balance that this device gives to your Nexstar 8.

Recently it has come to our attention that there is excessive slop in the fit between the 2 bracket halves at the rear of the scope. This applies to Brackets sold from June to December 2004. Enclosed is a small piece of UHMW (ultra high molecular weight) self adhesive tape. If you would separate your scope from the arm and apply the tape as shown in the picture below it will remove the slop.

This is mostly a cosmetic problem but the slop may make your scope more prone to vibration. Applying this shim tape will correct this. Do not worry that there is a now slight angle between the 2 plates, goto and tracking accuracy are based on optical alignment not mechanical.

We do apologize for the inconvenience and if you have any questions or concerns please feel free to call Frank at 800-933-3386 or Ray at 503-579-0276.

warm regards and clear skies,

Frank Dilatush & Ray Cooper

